

# Surface/Ceiling & Suspended Mount Installation



## Application

NL Linear luminaires are designed for use in hazardous locations, indoors, outdoors, wet locations, areas containing moisture, dirt, corrosion, vibration and rough usage. The NL Linear luminaire has been certified for use on marine vessels inside, outside, and in other severely wet saltwater environments. Suitable for mounting within 1.2m (4ft) of the ground. Suitable for wall mounting. Suitable for ceiling and suspension mounting.

Certified to: UL 844, UL 1598, UL 1598A, and UL 8750;  
CSA 22.2 No. 137, CSA 22.2 No. 250.0 and CSA22.2 No. 250.13  
ABS Listed \*PENDING\*

Hazardous Location Certification: Class I, Division 2, Groups ABCD;  
Class II, Division 2, Groups FG;  
Class III;  
Class I, Zone 2, Group IIC;  
(See chart below for T-Codes)

Housing: Copper-free Extruded and Cast Aluminium with Polycarbonate lens

Input Voltage: Based on luminaire suffix in table below: Suffix - AC: 120-277 VAC | Suffix - HV: 347-480 VAC

Electric Ratings:

Model	Input Voltage	Rated Wattage [Watts]	Rated Voltage [Volts]	Frequency [Hz]	Ambient Temp. Range [°C]	T-Codes (Class I Division 2)	T-Codes (Class II Division 2)
NL2S	AC	36	120-277	50/60	-40 to 55	T4A	T4
	HV	36	347-480	50/60	-40 to 54	T4A	T4
NL2H	AC	52	120-277	50/60	-40 to 55	T4A	T4
	HV	52	347-480	50/60	-40 to 54	T4A	T4
NL2X	AC	70	120-277	50/60	-40 to 52	T5	T4
	HV	82	347-480	50/60	-40 to 46	T5	T4A
NL4S	AC	85	120-277	50/60	-40 to 55	T4A	T4A
	HV	90	347-480	50/60	-40 to 54	T4A	T4A
NL4H	AC	105	120-277	50/60	-40 to 54	T4A	T4A
	HV	109	347-480	50/60	-40 to 52	T4A	T4A

Connections: 2 x 3/4" NPT Conduit | Black: Line | White: Neutral/Line 2 | Green: Ground  
Optional: Purple: 0-10V Dimming (+) | Grey: 0-10V Dimming (-)  
For connections use wire rated to a minimum of 90°C. Class 1 Wiring only. Dimming control wires must be rated 300V minimum for luminaires with suffix AC, 600V minimum for luminaires with suffix HV.  
End-to-end or daisy-chain wiring must use #12AWG conductors and the total circuit load must not exceed 1200W.

Temperature Range: See above Electrical Ratings chart

Ingress Protection: IP66 | Suitable For Wet Locations. Marine Outside Type (Salt Water)

## Warning

TO AVOID THE RISK OF FIRE, EXPLOSION, OR ELECTRIC SHOCK, THIS PRODUCT SHOULD BE INSTALLED, INSPECTED, AND MAINTAINED BY A QUALIFIED ELECTRICIAN ONLY, IN ACCORDANCE WITH ALL APPLICABLE ELECTRICAL CODES.

THIS LUMINAIRE MUST BE MOUNTED OR SUPPORTED INDEPENDENTLY OF AN OUTLET BOX.

CE PRODUIT DOIT ÊTRE INSTALLÉ CONFORMÉMENT AU CODE D'INSTALLATION APPLICABLE PAR UNE PERSONNE FAMILIAIRE AVEC LA CONSTRUCTION ET LE FONCTIONNEMENT DU PRODUIT ET LES DANGERS IMPLIQUÉS.

## Warning

POTENTIAL ELECTROSTATIC CHARGING HAZARD

## Warning

TO REDUCE THE RISK OF ELECTRIC SHOCK, DISCONNECT THE LUMINAIRE FROM THE SUPPLY CIRCUIT BEFORE OPENING FOR INSTALLATION AND SERVICING. KEEP TIGHTLY CLOSED WHEN IN OPERATION.

NO USER SERVICEABLE PARTS.

RISQUE POTENTIEL DE CHARGE ÉLECTROSTATIQUE - VOIR LES INSTRUCTIONS. POUR RÉDUIRE LE RISQUE DE COMBUSTION D'ATMOSPHÈRES DANGEREUSES, DÉBRANCHEZ LE LUMINAIRE DU CIRCUIT D'ALIMENTATION AVANT L'OUVERTURE. GARDER BIEN FERMÉ LORS DE L'UTILISATION.

AVOID ELECTROSTATIC DISCHARGE:

- CLEAN EXTERIOR LENS SURFACE WITH DAMP CLOTH ONLY

ÉVITEZ LES DÉCHARGES ÉLECTROSTATIQUES:

- NETTOYEZ LA SURFACE EXTÉRIEURE DE LA LENTILLE UNIQUEMENT AVEC UN CHIFFON HUMIDE

## Surface/Ceiling & Suspended Mount Installation (Ordered Separately)

(All brackets are ordered separately)

Refer to alternate instructions if using Angle Adjustable Mount

### Step 1.

Inspect shipping package and contents to ensure no damage has occurred during shipping.


### Step 2.

Install mounting brackets:


A) Fixed Mount (Standard Brackets): Loosen mounting brackets pre-installed on the back of the luminaire. Slide brackets outwards until mounting holes are 735mm apart for NL2 models, or 1332mm apart for NL4 models. Tighten provided 1/4-20 nut to a torque of 8 N-m (70 in-lbs). Fasten to flat surface using a minimum of one M6 or 1/4-20 fastener and washer per side (not provided). For installations subject to vibration of rough usage, a minimum of two fasteners per side are required. Mounting bracket is keyed for ease of installation.

Alternate Fixed Mounting: A minimum of two 1/4-20 Carriage bolts may be used to flush mount the luminaire. Insert head of carriage bolt into central opening and slide to desired mounting location.

B) Suspension Mounting: Remove fixed mounting brackets and associated fastener hardware from luminaire. Connect two anchors to each end-cap using the integral mounting holes as shown. Suspension hardware (not provided) must be rated for a minimum of 135 lbs.



Step 2A



Step 2B

## Step 3.

Open NL Lens using a 3mm hex tool and open lens.

Note: Screws are captive fasteners and will remain attached to the Lens for ease of reinstall and to prevent loss of fasteners.

## Step 4.

Remove reflector covering the wiring cavity closest to the open NPT entry. Loosen four M4 fasteners holding reflector in place and pinch to line up keyed slots with fasteners during removal.

## Step 5.

Make wiring connections.

A) For Single Entry Use: Wire using open NPT entry. Refer to NEC/CEC codes and follow all applicable local standards. See wiring diagram on Page 5.

B) For End-to-End Wiring: Remove all reflectors. Remove NPT blank from closed end using a 3/8" hex tool. Make wiring connections to provided splice connectors as shown in the wiring diagram. Conductors from the far side must be run through the channel between the AC Separator and case, as shown. All wiring methods must be in accordance with NEC/CEC codes, all local standards, and acceptable for the hazardous location of install.


C) For Class 1 dimming control circuit, wires must be rated to 300V minimum for luminaire models with suffix AC, 600V minimum rated wire for luminaires with suffix HV. For 0-10V Analog Dimming Control, connect Violet (+) and Gray (-) to 0-10VDC control wiring:

- Dimming controls must be certified and suitable for the classification of the area of their installation.
- The 0-10V dimming circuit can be wired as Class 1 or Class 2 Circuit.
- The LED Driver will source a maximum of 250 $\mu$ A for control needs.
- The 0-10V Controller must sink current from LED driver control leads
- 10V = maximum output, 0V = minimum output




NOTE: To aid in assembly and protection against ingress use of a petrolatum or soap thickened mineral oil based thread lubricant/sealant is necessary.

Un-used conduit opening must be plugged to maintain the integrity of the enclosure.

Step 4



Step 5B




NOTE: End-to-end or daisy-chain wiring must use #12AWG conductors and the total circuit load must not exceed 1200W.

## Step 6.


Reinstall reflectors and close lens: Reflector fasteners should be tightened by hand to 5 in-lbs torque to prevent stripping of screw channel threads. Close lens and reinstall M4 socket head cap screws using a 3mm hex driver. To align the lens fasteners with tapped holes, press on the lens to compress the gasket and direct fastener into tapped hole using 3mm hex driver. Torque lens fasteners to 1.7Nm (15 in-lbs).

## Mounting Dimensions:


NL2 - SURFACE/SUSPENSION MOUNT :




NL4 - SURFACE/SUSPENSION MOUNT :



## Wiring Diagram: AC (120-277VAC) & HV (347-480VAC) Models



## Wiring Diagram: AC (120-277VAC) & HV (347-480VAC) Models – End-to-End Wiring



## Angle Adjustable Mount Installation (Ordered Separately)

Refer to alternate instructions if using Surface/Ceiling & Suspended Mount

This SPX-BKT-NL-AM kit is intended for use with UL Listed NL luminaire as marked on the luminaire nameplate.

### Accessory Package Contents

SPX-BKT-NL-AM	QTY	PART NAME
	2	NL SWIVEL BRACKET
	2	M4 x 0.7 x 16mm SOCKET HEAD CAP SCREW

## Installation Steps

### Step 1.

Inspect shipping package and contents to ensure no damage has occurred during shipping. Discard surface/ceiling mounting bracket provided with NL luminaire.

### Step 2.

Loosen M4 socket head cap screws on swivel brackets using a 3mm hex tool. Slide bracket onto cylindrical boss on end-caps and loosely tighten.

### Step 3.

Mount luminaire using two M6 or 1/4-20 fasteners and washers per side (Not provided).

### Step 4.

Mounting bracket is keyed for ease of installation. Aim luminaire to desired angle and tighten M4 socket head cap screw on swivel brackets to a torque of 1.7Nm (15 in-lbs)


### Step 5.

Resume installation instructions provided with luminaire.



(STEP 3 in NL Installation Instructions provided with Luminaire)

## Mounting Dimensions:

NL2 - ANGLE ADJUSTABLE MOUNT (SPX-BKT-NL-AM):



NL4 - ANGLE ADJUSTABLE MOUNT (SPX-BKT-NL-AM):



Steps 2